

Paradox Engineering ALL Client Results

Answer/Options	Response Count
Session 1	1
Session 4	1
Session 12	1
Session	0
State Session Number (Reference below if needed):	3

Answer Options	Pass	Fail	Incon- clusive	Not Applicable	Out of Time	Response Count
Bootstrap Interface						
LightweightM2M-1.1-int-0 Client Initiated Bootstrap	1	0	0	2	0	3
LightweightM2M-1.1-int-Client Initiated Bootstrap Full (PSK)	1	0	0	2	0	3
LightweightM2M-1.1-int-2 Client Initiated Bootstrap Full (Cert)	0	0	0	3	0	3
LightweightM2M-1.1-int-3 Simple Bootstrap from Smartcard	0	0	0	3	0	3
LightweightM2M-1.1-int-4 Bootstrap Delete	1	0	0	2	0	3
LightweightM2M-1.1-int-5 Server Initiated Bootstrap	1	0	0	2	0	3
LightweightM2M-1.1-int-6 Bootstrap Sequence	1	0	0	2	0	3
LightweightM2M-1.1-int-7 Failback to bootstrap	1	0	0	2	0	3
LightweightM2M-1.1-int-8 Bootstrap Read	0	0	0	3	0	3
LightweightM2M-1.1-int-9 Bootstrap and Configuration Consistency	0	0	0	3	0	3
Registration Interface						
LightweightM2M-1.1-int-101 - Initial Registration	3	0	0	0	0	3
LightweightM2M-1.1-int-102 - Registration Update	3	0	0	0	0	3
LightweightM2M-1.1-int-103 - Deregistration	3	0	0	0	0	3
LightweightM2M-1.1-int-104 - Registration Update Trigger	3	0	0	0	0	3
LightweightM2M-1.1-int-105 - Discarded Register Update	2	0	0	1	0	3
LightweightM2M-1.1-int-106 - TCP Binding	0	0	0	3	0	3
LightweightM2M-1.1-int-107 - Extending the lifetime of a registration	3	0	0	0	0	3
LightweightM2M-1.1-int-108 - Turn on Queue Mode	0	0	0	3	0	3
LightweightM2M-1.1-int-109 - Behavior in Queue Mode	0	0	0	3	0	3
Device management & Service Enablement Interface						
LightweightM2M-1.1-int-201 - Querying basic information in Plain Text format	3	0	0	0	0	3
LightweightM2M-1.1-int-203 - Querying basic information in TLV format	3	0	0	0	0	3
LightweightM2M-1.1-int-204 - Querying basic information in JSON format	3	0	0	0	0	3
LightweightM2M-1.1-int-205 - Setting basic information in Plain Text format	3	0	0	0	0	3
LightweightM2M-1.1-int-211 - Querying basic information in CBOR format	3	0	0	0	0	3
LightweightM2M-1.1-int-212 - Setting basic information in CBOR format	3	0	0	0	0	3
LightweightM2M-1.1-int-215 - Setting basic information in TLV format	3	0	0	0	0	3
LightweightM2M-1.1-int-220 - Setting basic information in JSON format	1	1	0	1	0	3
LightweightM2M-1.1-int-221 - Attempt to perform operations on Security Object (ID: 0)	1	1	0	0	0	3
LightweightM2M-1.1-int-222 - Read on Object	3	0	0	0	0	3
LightweightM2M-1.1-int-223 - Read on Object Instance	3	0	0	0	0	3
LightweightM2M-1.1-int-224 - Read on Resource	3	0	0	0	0	3
LightweightM2M-1.1-int-225 - Read on Resource Instance	2	1	0	0	0	3
LightweightM2M-1.1-int-226 - Write (Partial) Update on Object Instance	3	0	0	0	0	3
LightweightM2M-1.1-int-227 - Write (replace) on Resource	3	0	0	0	0	3
LightweightM2M-1.1-int-228 - Write on Resource Instance	3	0	0	0	0	3
LightweightM2M-1.1-int-229 - Read-Composite Operation	1	1	0	1	0	3
LightweightM2M-1.1-int-230 - Write-Composite Operation	2	0	0	0	0	3
LightweightM2M-1.1-int-231 - Querying basic information in SenML JSON format	3	0	0	0	0	3
LightweightM2M-1.1-int-232 - Querying basic information in SenML CBOR format	3	0	0	0	0	3
LightweightM2M-1.1-int-233 - Setting basic information in SenML CBOR format	3	0	0	0	0	3
LightweightM2M-1.1-int-234 - Setting basic information in SenML JSON format	2	1	0	0	0	3
LightweightM2M-1.1-int-235 - Read-Composite Operation on root path	3	1	0	2	0	3
LightweightM2M-1.1-int-236 - Read-Composite - Partial Presence	0	0	0	2	0	3
LightweightM2M-1.1-int-237 - Read on Object without specifying Content-Type	2	0	0	1	0	3
LightweightM2M-1.1-int-241 - Executable Resource: Rebooting the device	3	0	0	0	0	3
LightweightM2M-1.1-int-256 - Write Operation Failure	3	0	0	0	0	3
LightweightM2M-1.1-int-257 - Write-Composite Operation	2	1	0	0	0	3
LightweightM2M-1.1-int-260 - Discover Command	1	1	0	0	0	3
LightweightM2M-1.1-int-261 - Write-Attribute Operation on a multiple resource	0	0	0	2	1	3
LightweightM2M-1.1-int-280 - Successful Read-Composite Operation	1	0	0	1	1	3
LightweightM2M-1.1-int-281 - Partially Successful Read-Composite Operation	0	0	0	2	1	3
INFORMATION REPORTING INTERFACE						
LightweightM2M-1.1-int-301 - Observation and Notification of parameter values	2	0	0	0	1	3
LightweightM2M-1.1-int-302 - Cancel Observations using Reset parameter	1	0	0	1	1	3
LightweightM2M-1.1-int-303 - Cancel observations using Observe with Cancel parameter	2	0	0	0	1	3
LightweightM2M-1.1-int-304 - Observe-Composite Operation	0	0	0	2	1	3
LightweightM2M-1.1-int-305 - Cancel Observation-Composite Operation	0	0	0	2	1	3
LightweightM2M-1.1-int-309 - Send Operation	0	0	0	0	0	3
LightweightM2M-1.1-int-307 - Muting Send	1	0	0	1	1	3
LightweightM2M-1.1-int-308 - Observe-Composite and Creating Object Instance	0	0	0	2	1	3
LightweightM2M-1.1-int-309 - Observe-Composite and Deleting Object Instance	0	0	0	2	1	3
LightweightM2M-1.1-int-310 - Observe-Composite and modification of parameter values	0	0	0	2</		

LightweightM2M-1.1-int-801 - Querying the readable resources of object	2	0	0	0	1	3
LightweightM2M-1.1-int-810 - Basic Observation and notification on Location Object Instance	2	0	0	0	1	3
CONNECTIVITY STATISTICS (ID 7)						
LightweightM2M-1.1-int-901 - Querying a Data Collection from Connectivity Object Instance	0	0	0	3	0	3
LightweightM2M-1.1-int-905 - Setting the writable resources	0	0	0	3	0	3
LightweightM2M-1.1-int-910 - Basic Observation and notification on Connectivity Monitoring Object Instance	0	0	0	3	0	3
Multi-Servers Context						
LightweightM2M-1.1-int-950 - Multi-Servers Registration	0	0	0	3	0	3
LightweightM2M-1.1-int-951 - Multi-Servers & Attributes	0	0	0	3	0	3
CELLULAR NETWORK CONNECTIVITY (ID 10)						
LightweightM2M-1.1-int-1200 - Querying the readable resources of Object ID:10	0	0	0	3	0	3
LightweightM2M-1.1-int-1201 - Querying the readable resources of Object ID:10 in version 1.1	0	0	0	3	0	3
LightweightM2M-1.1-int-1202 - Setting the Power Saving Mode Resources of Object ID:10	0	0	0	3	0	3
LightweightM2M-1.1-int-1203 - Observation and notification on Object ID:10 related to Power Saving Mode Resources	0	0	0	3	0	3
LightweightM2M-1.1-int-1204 - Observation and notification on Object ID: 10 related to timers	0	0	0	3	0	3
APN CONNECTION PROFILE (ID 11)						
LightweightM2M-CONMGMT-1.1-int-1250 - APN configuration	0	0	0	3	0	3
BEARER SELECTION (ID 13)						
LightweightM2M-CONMGMT-1.1-int-1350 - Bearer Selection	0	0	0	3	0	3
PORTFOLIO OBJECT (ID 16)						
LightweightM2M-1.1-int-1630 - Create Portfolio Object Instance	1	0	0	1	1	3
LightweightM2M-1.1-int-1635 - Delete Portfolio Object Instance	1	0	0	1	1	3
BinaryAppDataContainer Object (ID 19)						
LightweightM2M-1.1-int-1900 - Observation and notification on Object ID: 19	0	0	0	3	0	3
LightweightM2M-1.1-int-1901 - Setting the writable Resource Data	0	0	0	3	0	3
Event Log Object (ID 20)						
LightweightM2M-1.1-int-2000 - Control the Log Function	0	0	0	3	0	3
LightweightM2M-1.1-int-2001 - Querying the readable resources	0	0	0	3	0	3
Totals	116	9	0	173	22	320