



# **Enabler Test Specification for Lightweight M2M**

Draft Version 1.0 – 16 Sept 2015

---

**Open Mobile Alliance**  
OMA-ETS-LightweightM2M-V1\_0-20150916-D

Use of this document is subject to all of the terms and conditions of the Use Agreement located at <http://www.openmobilealliance.org/UseAgreement.html>.

Unless this document is clearly designated as an approved specification, this document is a work in process, is not an approved Open Mobile Alliance™ specification, and is subject to revision or removal without notice.

You may use this document or any part of the document for internal or educational purposes only, provided you do not modify, edit or take out of context the information in this document in any manner. Information contained in this document may be used, at your sole risk, for any purposes. You may not use this document in any other manner without the prior written permission of the Open Mobile Alliance. The Open Mobile Alliance authorizes you to copy this document, provided that you retain all copyright and other proprietary notices contained in the original materials on any copies of the materials and that you comply strictly with these terms. This copyright permission does not constitute an endorsement of the products or services. The Open Mobile Alliance assumes no responsibility for errors or omissions in this document.

Each Open Mobile Alliance member has agreed to use reasonable endeavors to inform the Open Mobile Alliance in a timely manner of Essential IPR as it becomes aware that the Essential IPR is related to the prepared or published specification. However, the members do not have an obligation to conduct IPR searches. The declared Essential IPR is publicly available to members and non-members of the Open Mobile Alliance and may be found on the “OMA IPR Declarations” list at <http://www.openmobilealliance.org/ipr.html>. The Open Mobile Alliance has not conducted an independent IPR review of this document and the information contained herein, and makes no representations or warranties regarding third party IPR, including without limitation patents, copyrights or trade secret rights. This document may contain inventions for which you must obtain licenses from third parties before making, using or selling the inventions. Defined terms above are set forth in the schedule to the Open Mobile Alliance Application Form.

NO REPRESENTATIONS OR WARRANTIES (WHETHER EXPRESS OR IMPLIED) ARE MADE BY THE OPEN MOBILE ALLIANCE OR ANY OPEN MOBILE ALLIANCE MEMBER OR ITS AFFILIATES REGARDING ANY OF THE IPR'S REPRESENTED ON THE “OMA IPR DECLARATIONS” LIST, INCLUDING, BUT NOT LIMITED TO THE ACCURACY, COMPLETENESS, VALIDITY OR RELEVANCE OF THE INFORMATION OR WHETHER OR NOT SUCH RIGHTS ARE ESSENTIAL OR NON-ESSENTIAL.

THE OPEN MOBILE ALLIANCE IS NOT LIABLE FOR AND HEREBY DISCLAIMS ANY DIRECT, INDIRECT, PUNITIVE, SPECIAL, INCIDENTAL, CONSEQUENTIAL, OR EXEMPLARY DAMAGES ARISING OUT OF OR IN CONNECTION WITH THE USE OF DOCUMENTS AND THE INFORMATION CONTAINED IN THE DOCUMENTS.

© 2015 Open Mobile Alliance Ltd. All Rights Reserved.

Used with the permission of the Open Mobile Alliance Ltd. under the terms set forth above.

# Contents

1.	SCOPE.....	5
2.	REFERENCES .....	6
2.1	NORMATIVE REFERENCES.....	6
2.2	INFORMATIVE REFERENCES.....	6
3.	TERMINOLOGY AND CONVENTIONS.....	7
3.1	CONVENTIONS.....	7
3.2	DEFINITIONS.....	7
3.3	ABBREVIATIONS .....	8
4.	INTRODUCTION .....	9
5.	LIGHTWEIGHTM2M CONFORMANCE TEST CASES.....	10
6.	LIGHTWEIGHTM2M INTEROPERABILITY TEST CASES .....	11
6.1	LWM2M CORE SPECIFICATION TEST CASES [0-999].....	11
6.1.1	Bootstrap Interface: [0-99].....	11
6.1.2	Registration Interface [100-199].....	11
6.1.2.1	LightweightM2M-1.0-int-101 – Initial Registration.....	11
6.1.2.2	LightweightM2M-1.0-int-102 – Registration Update.....	12
6.1.2.3	LightweightM2M-1.0-int-103 – Deregistration.....	13
6.1.2.4	LightweightM2M-1.0-int-104 – Registration Update Trigger.....	13
6.1.2.5	LightweightM2M-1.0-int-105 – Initial Registration to Bootstrap Server.....	14
6.1.3	Device management & Service Enablement Interface [200-299].....	15
6.1.3.1	LightweightM2M-1.0-int-201 – Querying basic information in Plain Text format.....	15
6.1.3.2	LightweightM2M-1.0-int-202 – Querying basic information in Opaque format.....	15
6.1.3.3	LightweightM2M-1.0-int-203 – Querying basic information in TLV format.....	16
6.1.3.4	LightweightM2M-1.0-int-204 – Querying basic information in JSON format.....	17
6.1.3.5	LightweightM2M-1.0-int-205 – Setting basic information in Plain Text format.....	18
6.1.3.6	LightweightM2M-1.0-int-210 – Setting basic information in Opaque format.....	18
6.1.3.7	LightweightM2M-1.0-int-215 – Setting basic information in TLV format.....	18
6.1.3.8	LightweightM2M-1.0-int-220 – Setting basic information in JSON format.....	18
6.1.3.9	LightweightM2M-1.0-int-241 – Executable Resource: Rebooting the device.....	19
6.1.3.10	LightweightM2M-1.0-int-260 – Discover Command.....	19
6.1.3.11	LightweightM2M-1.0-int-270 – Create Object Instance.....	19
6.1.3.12	LightweightM2M-1.0-int-271 – Create Multiple Resource Instance.....	19
6.1.3.13	LightweightM2M-1.0-int-290 – Delete Object Instance.....	19
6.1.4	Information Reporting Interface [300-399].....	20
6.1.4.1	LightweightM2M-1.0-int-301 – Observation and Notification of parameter values.....	20
6.1.4.2	LightweightM2M-1.0-int-302 – Cancel Observations using Reset Operation.....	21
6.1.4.3	LightweightM2M-1.0-int-303 – Cancel observations using Observe with Cancel parameter (to be updated).....	21
6.1.5	Security [400-499].....	22
6.1.5.1	LightweightM2M-1.0-int-401 – UDP Channel Security – Pre-shared Key Mode.....	22
6.1.6	Core Specific Objects Test cases [500-999] .....	22
6.1.6.1	Security Object (ID 0) [500-549].....	22
6.1.6.2	Server Object (ID 1) [550-599] .....	22
6.1.6.2.1	LightweightM2M-1.0-int-551 – Querying the readable resources of object.....	23
6.1.6.2.2	LightweightM2M-1.0-int-555 – Setting the writable resources.....	24
6.1.6.2.3	LightweightM2M-1.0-int-560 – Observation and notification of observable resources.....	25
6.1.6.3	Access Control Object (ID 2) [600-649].....	25
6.1.6.4	LWM2M Server (ID 3) [650-699].....	25
6.1.6.4.1	LightweightM2M-1.0-int-651 – Querying the readable resources of object.....	26
6.1.6.4.2	LightweightM2M-1.0-int-652 – Querying the firmware version from the client.....	27
6.1.6.4.3	LightweightM2M-1.0-int-655 – Setting the writable resources.....	27
6.1.6.4.4	LightweightM2M-1.0-int-660 – Observation and notification of observable resources.....	28
6.1.6.5	LWM2M Connectivity Monitoring (ID 4) [700-749] .....	29
6.1.6.5.1	LightweightM2M-1.0-int-701 – Querying the readable resources of object.....	29
6.1.6.5.2	LightweightM2M-1.0-int-705 – Setting the writable resources.....	29
6.1.6.5.3	LightweightM2M-1.0-int-710 – Observation and notification of observable resources.....	30
6.1.6.6	Firmware Update Object (ID 5) [750-799].....	31

6.1.6.6.1	LightweightM2M-1.0-int-751 – Querying the readable resources .....	31
6.1.6.6.2	LightweightM2M-1.0-int-755 – Setting the writable resources.....	32
6.1.6.6.3	LightweightM2M-1.0-int-760 – Observation and notification of observable resources .....	33
6.1.6.6.4	LightweightM2M-1.0-int-770 – Successful Firmware update (via COAP).....	33
6.1.6.6.5	LightweightM2M-1.0-int-771 – Successful Firmware update (via alternative mechanism).....	35
6.1.6.6.6	LightweightM2M-1.0-int-772 – Error Case: firmware package not downloaded.....	36
6.1.6.6.7	LightweightM2M-1.0-int-773 – Error Case: not enough storage .....	37
6.1.6.6.8	LightweightM2M-1.0-int-774 – Error Case: out of memory .....	38
6.1.6.6.9	LightweightM2M-1.0-int-775 – Error Case: Connection lost during download (package URI) .....	39
6.1.6.6.10	LightweightM2M-1.0-int-776 – Error Case: CRC check fail .....	40
6.1.6.6.11	LightweightM2M-1.0-int-777 – Error Case: unsupported package type .....	41
6.1.6.6.12	LightweightM2M-1.0-int-778 – Error Case: invalid URI (package URI) .....	42
6.1.6.6.13	LightweightM2M-1.0-int-779 – Error Case: Unsuccessful Firmware Update.....	43
6.1.6.7	<i>Location Object (ID 6) [800-849]</i> .....	45
6.1.6.7.1	LightweightM2M-1.0-int-801 – Querying the readable resources of object.....	45
6.1.6.7.2	LightweightM2M-1.0-int-805 – Setting the writable resources.....	45
6.1.6.7.3	LightweightM2M-1.0-int-810 – Observation and notification of observable resources .....	45
6.1.6.8	<i>Connectivity Statistics (ID 7) [900-949]</i> .....	47
6.1.6.8.1	LightweightM2M-1.0-int-901 – Querying the readable resources of object.....	47
6.1.6.8.2	LightweightM2M-1.0-int-905 – Setting the writable resources.....	47
6.1.6.8.3	LightweightM2M-1.0-int-910 – Observation and notification of observable resources .....	48
<b>6.2</b>	<b>LWM2M ADDITIONAL OBJECTS TEST CASES [1000-1999]</b> .....	<b>48</b>
6.2.1	Lock and Wipe Object (ID 8) [1000-1099].....	48
6.2.2	Software Management Object (ID 9) [1100-1199].....	48
6.2.3	Connectivity Management Objects (ID 10, 11, 12, 13) [1200-1499].....	49
6.2.3.1	<i>LightweightM2M-CONMGMT-1.0-int-1201 – APN configuration</i> .....	49
6.2.3.2	<i>LightweightM2M-CONMGMT-1.0-int-1202 – Bearer Selection</i> .....	50
6.2.4	Device Capability Management Object (ID 15) [1500-1599].....	50
<b>APPENDIX A.</b>	<b>CHANGE HISTORY (INFORMATIVE)</b> .....	<b>51</b>
<b>A.1</b>	<b>APPROVED VERSION HISTORY</b> .....	<b>51</b>
<b>A.2</b>	<b>DRAFT/CANDIDATE VERSION 1.0 HISTORY</b> .....	<b>51</b>
<b>APPENDIX B.</b>	<b>ADDITIONAL INFORMATION</b> .....	<b>52</b>
<b>B.1</b>	<b>EXAMPLE OF TEST CONFIGURATION AND SETUP</b> .....	<b>52</b>

# 1. Scope

This document describes in detail available test cases for LightweightM2M as specified in OMA-TS-LightweightM2M-V1\_0.

The test cases are split in two categories, conformance and interoperability test cases.

The conformance test cases are aimed to verify the adherence to normative requirements described in the technical specifications.

The interoperability test cases are aimed to verify that implementations of the specifications work satisfactory.

If either conformance or interoperability tests do not exist at the creation of the test specification this part should be marked not available.

## 2. References

### 2.1 Normative References

- [3GPP-TS\_23.003] 3GPP TS 23.003 “Numbering, addressing and identification”
- [CoAP] Shelby, Z., Hartke, K., Bormann, C., and B. Frank, "Constrained Application Protocol (CoAP)", draft-ietf-core-coap-18, Jun 2013.
- [ETSI TS 102.221] “Smart Cards; UICC-Terminal interface; Physical and logical characteristics”, (ETSI TS 102 221 release 11), [URL:http://www.etsi.org/](http://www.etsi.org/)
- [GlobalPlatform SCP 02] GlobalPlatform v2.2.1 - January 2011 - Appendix E: Secure Channel Protocol 02 (SCP 02)
- [IOPPROC] “OMA Interoperability Policy and Process”, Version 1.1, Open Mobile Alliance™, OMA-IOP-Process-V1\_1, [URL:http://www.openmobilealliance.org/](http://www.openmobilealliance.org/)
- [LWM2M-AD] “Lightweight Machine to Machine Architecture”, Open Mobile Alliance™, OMA-AD-LightweightM2M-V1\_0, [URL:http://www.openmobilealliance.org/](http://www.openmobilealliance.org/)
- [LWM2M-TS] “Lightweight Machine to Machine Technical Specification”, Open Mobile Alliance™, OMA-TS-LightweightM2M-V1\_0, [URL:http://www.openmobilealliance.org/](http://www.openmobilealliance.org/)
- [OBSERVE] Hartke, K. “Observing Resources in CoAP”, draft-ietf-core-observe-11 (work in progress), Oct 2013.
- [PKCS#15] PKCS #15 v1.1: Cryptographic Token Information Syntax Standard”, RSA Laboratories, June 6, 2000. [URL:ftp://ftp.rsasecurity.com/pub/pkcs/pkcs-15/pkcs-15v1\\_1.pdf](ftp://ftp.rsasecurity.com/pub/pkcs/pkcs-15/pkcs-15v1_1.pdf)
- [RFC2119] “Key words for use in RFCs to Indicate Requirement Levels”, S. Bradner, March 1997, [URL:http://www.ietf.org/rfc/rfc2119.txt](http://www.ietf.org/rfc/rfc2119.txt)
- [RFC2234] “Augmented BNF for Syntax Specifications: ABNF”. D. Crocker, Ed., P. Overell. November 1997, [URL:http://www.ietf.org/rfc/rfc2234.txt](http://www.ietf.org/rfc/rfc2234.txt)
- [RFC4122] “A Universally Unique Identifier (UUID) URN Namespace”, P. Leach, et al. July 2005, [URL:http://www.ietf.org/rfc/rfc4122.txt](http://www.ietf.org/rfc/rfc4122.txt)
- [RFC5246] The Transport Layer Security (TLS) Protocol Version 1.2
- [RFC5289] TLS Elliptic Curve Cipher Suites with SHA-256/384 and AES Galois Counter Mode (GCM)
- [RFC5487] Pre-Shared Key Cipher Suites for TLS with SHA-256/384 and AES Galois Counter Mode
- [RFC6347] Rescorla, E. and N. Modadugu, "Datagram Transport Layer Security Version 1.2", [RFC6347](https://tools.ietf.org/html/rfc6347), January 2012.
- [RFC6655] McGrew, D. and D. Bailey, "AES-CCM Cipher Suites for TLS", RFC6655, July 2012.
- [RFC6690] Shelby, Z. “Constrained RESTful Environments (CoRE) Link Format”, RFC6690, Aug 2012.

### 2.2 Informative References

- [DMREPPRO] “OMA Device Management Representation Protocol, Version 1.3”. Open Mobile Alliance™. OMA-TS-DM\_RepPro-V1\_3. [URL:http://www.openmobilealliance.org/](http://www.openmobilealliance.org/)
- [OMADICT] “Dictionary for OMA Specifications”, Version 2.9, Open Mobile Alliance™, OMA-ORG-Dictionary-V2\_9, [URL:http://www.openmobilealliance.org/](http://www.openmobilealliance.org/)

## 3. Terminology and Conventions

### 3.1 Conventions

The key words “MUST”, “MUST NOT”, “REQUIRED”, “SHALL”, “SHALL NOT”, “SHOULD”, “SHOULD NOT”, “RECOMMENDED”, “MAY”, and “OPTIONAL” in this document are to be interpreted as described in [RFC2119].

All sections and appendixes, except “Scope”, are normative, unless they are explicitly indicated to be informative.

The following numbering scheme is used:

**xxx-y.z-con-number** where:

xxx	Name of enabler, e.g. MMS or Browsing
y.z	Version of enabler release, e.g. 1.2 or 1.2.1
'con'	Indicating this test is a conformance test case
number	Leap number for the test case

Or

**xxx-y.z-int-number** where:

xxx	Name of enabler, e.g. MMS or Browsing
y.z	Version of enabler release, e.g. 1.2 or 1.2.1
'int'	Indicating this test is a interoperability test case
number	Leap number for the test case

### 3.2 Definitions

Application	1) The customer's realisation of a service through M2M - e.g. satnav, smart metering 2) Individual software components that run on top of the device's operating system. Access Point Name
Device	The hardware that is realising a function for the customer e.g. a smart meter.
Module	A modular component of a device e.g. the radio module housing the SIM

### 3.3 Abbreviations

<b>API</b>	Application Programming Interface
<b>APN</b>	Access Point Name
<b>CoAP</b>	Constrained Application Protocol
<b>CON</b>	Conformance
<b>DM</b>	Device Management
<b>GDSP</b>	Global Data Service Platform
<b>GUI</b>	Graphical User Interface
<b>IMEI</b>	International Mobile Equipment Identity
<b>IMSI</b>	International Mobile Subscriber Identity
<b>IOP</b>	Interoperability
<b>LWM2M</b>	Lightweight Machine to Machine (refers to this OMA enabler)
<b>M2M</b>	Machine to Machine
<b>MSISDN</b>	Mobile Station International Subscriber Directory Number
<b>OMA</b>	Open Mobile Alliance
<b>OpCo</b>	Operating Company
<b>OS</b>	Operating System
<b>SIM</b>	Subscriber Interface Module
<b>UI</b>	User Interface

## 4. Introduction

The purpose of this document is to provide test cases for LightweightM2M Enabler Release V1.0.

The implementation of some features is optional for the Clients and/or the Servers in the LightweightM2M Enabler. The tests associated with these optional features are marked as "(Includes Optional Features)" in the test specification.

The following items on an overall level are needed to adequately test the LWM2M enabler:

- A LWM2M server
- A LWM2M client e.g. embedded in a M2M device or module connected via UDP and SMS with the LWM2M server

The LWM2M enabler tests are carried out using the LWM2M protocol and objects, and using the underlying protocols such as [CoAP].

## 5. LightweightM2M Conformance Test Cases

None.

## 6. LightweightM2M Interoperability Test Cases

### 6.1 LWM2M Core Specification Test cases [0-999]

#### 6.1.1 Bootstrap Interface: [0-99]

<Test Cases to fill-up>

#### 6.1.2 Registration Interface [100-199]

##### 6.1.2.1 LightweightM2M-1.0-int-101 – Initial Registration

<b>Test Case Id</b>	LightweighthM2M-1.0-int-101
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Test that the Client registers with the Server.
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is turned on</li> <li>○ The bootstrap procedure has been completed or the required bootstrap information is available to the client</li> <li>○ The client contains the following mandatory LWM2M 1.0 objects instances. <ul style="list-style-type: none"> <li>– LWM2M Server Object (ID=1) Instance 0 with mandatory resources and Short Server ID=1</li> <li>– LWM2M Security Object (ID = 0) Instance 0 with mandatory resources and Bootstrap Server =False</li> <li>– LWM2M Device Object (ID=3) Instance 0 with mandatory resources.</li> </ul> </li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. Device is switched on and bootstrap information is available to the device.</li> <li>2. The device automatically registers at the server, once this information is available.</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. Registration message (COAP POST) is sent from client to server.</li> <li>b. Client receives Success message (2.01 Created) from the server.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. Server has received REGISTER operation</li> <li>2. Server knows the following <ul style="list-style-type: none"> <li>• Endpoint Client Name</li> <li>• registration lifetime (optional)</li> <li>• LWM2M version (optional)</li> <li>• binding mode (optional)</li> <li>• SMS number (optional)</li> <li>• Objects and Object Instances (mandatory and optional objects / object instances)</li> </ul> </li> <li>3. Client has received “Success” message from server</li> </ol>

### 6.1.2.2 LightweightM2M-1.0-int-102 – Registration Update

<b>Test Case Id</b>	LightweighthM2M-1.0-int-102
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Test that the client updates the registration information on the server.
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Need exists to re-register, e.g. previous registration has expired.</li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. Switch on device and try to Re-Register</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. Re-Registration message (COAP PUT) is sent from client to server.</li> <li>b. Client receives Success message (2.04 Changed) from the server.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. Server has received REGISTER operation</li> <li>2. Server knows the following <ul style="list-style-type: none"> <li>• Endpoint Client Name</li> <li>• registration lifetime (optional)</li> <li>• LWM2M version (optional)</li> <li>• binding mode (optional)</li> <li>• SMS number (optional)</li> <li>• Objects and Object Instances (optional)</li> </ul> </li> <li>3. Client has received “Success” message from server</li> </ol>

### 6.1.2.3 LightweightM2M-1.0-int-103 – Deregistration

<b>Test Case Id</b>	LightweighthM2M-1.0-int-103
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Test that the client is able to deregister at the server.
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>o Client is registered</li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. Client will no longer be available, thus, it should de-register</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. Deregistration message (COAP DELETE) is sent from client to server.</li> <li>b. Client receives Success message (2.02 Deleted) from the server.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. Client is removed from the servers registration database</li> </ol>

### 6.1.2.4 LightweightM2M-1.0-int-104 – Registration Update Trigger

<b>Test Case Id</b>	LightweighthM2M-1.0-int-104
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Test that the Client registers with the Server when triggered with the Registration Update Trigger (see LWM2M server object)
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>o Device is turned on</li> <li>o The bootstrap procedure has been completed or the required bootstrap information is available to the client</li> <li>o The client has a LWM2M Server Object Instance.</li> <li>o The device is registered with the server.</li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. Binding is set to U (as in TS section 5.2.1.1)</li> <li>2. De-registration is performed, or, alternatively registration expires</li> <li>3. Server sends Registration Update Trigger via SMS</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. Binding is set by sending COAP PUT 1/7 with string content “U” from server to device</li> <li>b. Server receives Success message (2.04 Changed) from the device</li> <li>c. Device registration expires on the server (for test purposes a short registration lifetime could be chosen)</li> <li>d. Registration Update Trigger message COAP POST 1/8 is sent from server to client via SMS</li> <li>e. Re-Registration message (COAP PUT) is sent from client to server via UDP</li> <li>f. Client receives Success message (2.04 Changed) from the server.</li> </ol>

<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. Server has received REGISTER operation via UDP</li> <li>2. Server knows the following <ul style="list-style-type: none"> <li>• Endpoint Client Name</li> <li>• registration lifetime (optional)</li> <li>• LWM2M version (optional)</li> <li>• binding mode (optional)</li> <li>• SMS number (optional)</li> <li>• Objects and Object Instances (optional)</li> </ul> </li> <li>3. Client has received “Success” message from server</li> </ol>
----------------------	---

### 6.1.2.5 LightweightM2M-1.0-int-105 – Initial Registration to Bootstrap Server

<b>Test Case Id</b>	LightweighthM2M-1.0-int-105
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Test that the Client registers with the Bootstrap Server.
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is turned on</li> <li>○ The required Bootstrap Server Bootstrap information is available to the Client</li> <li>○ The client contains the following mandatory LWM2M 1.0 objects instances <ul style="list-style-type: none"> <li>– LWM2M Server Object (ID=1) Instance 0 with mandatory resources and Short Server ID=1</li> <li>– LWM2M Security Object (ID = 0) Instance 0 with mandatory resources and Bootstrap Server =True</li> <li>– LWM2M Device Object (ID=3) Instance 0 with mandatory resources</li> </ul> </li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. Device is switched on and Bootstrap Server Bootstrap information is available to the device.</li> <li>2. The device automatically registers at the Bootstrap Server, once this information is available.</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. Registration message (COAP POST) is sent from client to Bootstrap Server.</li> <li>b. Client receives Success message (2.01 Created) from the Bootstrap Server.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. Bootstrap Server has received REGISTER operation</li> <li>2. Bootstrap Server knows the following <ul style="list-style-type: none"> <li>• Endpoint Client Name</li> <li>• registration lifetime (optional)</li> <li>• LWM2M version (optional)</li> <li>• binding mode (optional)</li> <li>• SMS number (optional)</li> <li>• Objects and Object Instances (mandatory object Instances only)</li> </ul> </li> <li>3. Client has received “Success” message from Bootstrap Server</li> </ol>

### 6.1.3 Device management & Service Enablement Interface [200-299]

#### 6.1.3.1 LightweightM2M-1.0-int-201 – Querying basic information in Plain Text format

<b>Test Case Id</b>	LightweighthM2M-1.0-int-201
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	<p>Querying the following data on the client (Device Object: ID 3):</p> <ul style="list-style-type: none"> <li>• Manufacturer</li> <li>• Model number</li> <li>• Serial number</li> </ul>
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> </ul>
<b>Test Procedure</b>	<p>1. A READ operation from server on these resources has been received by the client.</p> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. READ (COAP GET) on device object resources, with the CoAP Accept option to indicate the requested content format: Plain Text</li> <li>b. Server receives success message (2.05 Content) and the requested values in the requested format.</li> </ol>
<b>Pass-Criteria</b>	<p>1. Server has received the requested information and display of the following data to the user is possible:</p> <ul style="list-style-type: none"> <li>• Manufacturer</li> <li>• Model number</li> <li>• Serial number</li> </ul>

#### 6.1.3.2 LightweightM2M-1.0-int-202 – Querying basic information in Opaque format

<Test Cases to fill-up>

### 6.1.3.3 LightweightM2M-1.0-int-203 – Querying basic information in TLV format

<b>Test Case Id</b>	LightweighthM2M-1.0-int-203
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	<p>Querying the following data on the client (Device Object: ID 3):</p> <ul style="list-style-type: none"> <li>• Manufacturer</li> <li>• Model number</li> <li>• Serial number</li> </ul>
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>o Device is registered at the LWM2M server</li> </ul>
<b>Test Procedure</b>	<p>a. A READ operation from server on these resources has been received by the client.</p> <p>Normal flow:</p> <p>b. READ (COAP GET) on device object resources, with the CoAP Accept option to indicate the requested content format: TLV</p> <ul style="list-style-type: none"> <li>i. Bits 7-6=00= Object Instance in which case the Value contains one or more Resource TLVs</li> <li>ii. Bits 7-6=11= Resource with Value</li> </ul> <p>c. Server receives success message (2.05 Content) and the requested values in the requested format.</p>
<b>Pass-Criteria</b>	<p>1. Server has received the requested information and display of the following data to the user is possible:</p> <ul style="list-style-type: none"> <li>• Manufacturer</li> <li>• Model number</li> <li>• Serial number</li> </ul>

#### 6.1.3.4 LightweightM2M-1.0-int-204 – Querying basic information in JSON format

<b>Test Case Id</b>	LightweighthM2M-1.0-int-204
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	<p>Querying the following data on the client (Device Object: ID 3):</p> <ul style="list-style-type: none"> <li>• Manufacturer</li> <li>• Model number</li> <li>• Serial number</li> </ul>
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. A READ operation from server on these resources has been received by the client.</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. READ (COAP GET) on device object resources, with the CoAP Accept option to indicate the requested content format: JSON</li> <li>b. Server receives success message (2.05 Content) and the requested values in the corresponding format.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. Server has received the requested information and display of the following data to the user is possible: <ul style="list-style-type: none"> <li>• Manufacturer</li> <li>• Model number</li> <li>• Serial number</li> </ul> </li> </ol>

### 6.1.3.5 LightweightM2M-1.0-int-205 – Setting basic information in Plain Text format

<b>Test Case Id</b>	LightweightM2M-1.0-int-205
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Setting the writable resources of object 1 (Server Object: ID 1):
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>o Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from server on the resource has been received by the client. This test has to be run for the following resources:</p> <ol style="list-style-type: none"> <li>a) Lifetime</li> <li>b) Default minimum period</li> <li>c) Default maximum period</li> <li>d) Disable timeout</li> <li>e) Notification storing when disabled or offline</li> <li>f) Binding</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. WRITE (CoAP PUT/POST) on the resource with a value admissible with regards to LWM2M technical specification</li> <li>2. Server receives success message (2.04 Changed)</li> <li>3. The server READs the result of the WRITE operation by querying the resource.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server receives the status code “2.04”</li> <li>2. The resource value has changed according to WRITE request</li> </ol>

### 6.1.3.6 LightweightM2M-1.0-int-210 – Setting basic information in Opaque format

<Test Cases to fill-up>

### 6.1.3.7 LightweightM2M-1.0-int-215 – Setting basic information in TLV format

<Test Cases to fill-up>

### 6.1.3.8 LightweightM2M-1.0-int-220 – Setting basic information in JSON format

<Test Cases to fill-up>

**6.1.3.9 LightweightM2M-1.0-int-241 – Executable Resource: Rebooting the device**

<b>Test Case Id</b>	LightweighthM2M-1.0-int-241
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Test that rebooting of the device remotely through the server is possible (Device Object: ID 3).
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is switched on and registered with the server. (Device might be in a state that requires a reboot)</li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. An EXECUTE operation from server on the resource object/reboot has been received by the client.</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. Server performs Execute (COAP POST) on device/reboot resource</li> <li>b. Server receives success message (2.04 Changed) from client</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. Device reboots successfully and re-registers at the server again</li> </ol>

**6.1.3.10 LightweightM2M-1.0-int-260 – Discover Command**

&lt;Test Cases to fill-up&gt;

**6.1.3.11 LightweightM2M-1.0-int-270 – Create Object Instance**

&lt;Test Cases to fill-up&gt;

**6.1.3.12 LightweightM2M-1.0-int-271 – Create Multiple Resource Instance**

&lt;Test Cases to fill-up&gt;

**6.1.3.13 LightweightM2M-1.0-int-290 – Delete Object Instance**

&lt;Test Cases to fill-up&gt;

## 6.1.4 Information Reporting Interface [300-399]

### 6.1.4.1 LightweightM2M-1.0-int-301 – Observation and Notification of parameter values

<b>Test Case Id</b>	LightweighthM2M-1.0-int-301
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Sending the observation policy to the device.
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational.</li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. The Server establishes an Observation relationship with the Client to acquire conditional notifications about: <ul style="list-style-type: none"> <li>• Line Voltage</li> <li>• Signal Strength</li> </ul> </li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. Server communicates to the device min/max period, threshold value and step with a WRITE ATTRIBUTE (COAP PUT) operation</li> <li>b. Server sends OBSERVE (COAP Observe Option) message to activate reporting</li> <li>c. Client reports requested information with a NOTIFY message (COAP responses)</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server has received the requested information and display of “Line Voltage” and “Signal Strength” to the user is possible.</li> </ol>

#### 6.1.4.2 LightweightM2M-1.0-int-302 – Cancel Observations using Reset Operation

<b>Test Case Id</b>	LightweightM2M-1.0-int-302
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Cancel the Observation relationship by sending “Cancel Observation” operation.
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational.</li> <li>○ Server established Observation relationship with the Client.</li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. The Server removes a pre-established Observation relationship by sending “Cancel Observation”. The Client removes conditional notifications about: <ul style="list-style-type: none"> <li>• Power Source Voltage</li> <li>• Signal Strength</li> </ul> </li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. Client reports requested information with a NOTIFY message (COAP responses)</li> <li>b. Server sends Cancel Observe (COAP RESET message) to cancel the Observation relationship.</li> <li>c. Client stops reporting requested information and removes associated entries from the list of observers.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server stops receiving information on “Line Voltage” and “Signal Strength” and associated entries from the list of observers are removed.</li> </ol>

#### 6.1.4.3 LightweightM2M-1.0-int-303 – Cancel observations using Observe with Cancel parameter (to be updated)

<b>Test Case Id</b>	LightweightM2M-1.0-int-303
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational.</li> <li>○ Server established Observation relationship with the Client.</li> </ul>
<b>Test Procedure</b>	
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server stops receiving information on “Line Voltage” and “Signal Strength” and associated entries from the list of observers are removed.</li> </ol>

## 6.1.5 Security [400-499]

### 6.1.5.1 LightweightM2M-1.0-int-401 – UDP Channel Security – Pre-shared Key Mode

<b>Test Case Id</b>	LightweighthM2M-1.0-int-401
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Establishing DTLS session using UDP pre-shared key mode
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ The bootstrap procedure has been completed or the required bootstrap information is available to the client.</li> <li>○ The bootstrap information includes the Security Mode resource of the object LWM2M Security set to 0: Pre-Shared Key mode</li> <li>○ The client has a LWM2M Server Object Instance.</li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. Device is switched on and bootstrap information is available to the device.</li> <li>2. The device automatically registers at the server, once this information is available and a DTLS session is established between client and server.</li> <li>3. Using this DTLS session, GET commands are sent from the server to the client, and the client sends back the requested resource values.</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. Registration message (COAP POST) is sent from client to server.</li> <li>b. Client receives Success message (2.01 Created) from the server.</li> <li>c. READ (COAP GET) on e.g. ACL object resources</li> <li>d. Server receives success message (2.05 Content) and the requested values (encrypted)</li> </ol>
<b>Pass-Criteria</b>	<ul style="list-style-type: none"> <li>• Registration and READ commands work successfully over DTLS session.</li> </ul>

## 6.1.6 Core Specific Objects Test cases [500-999]

### 6.1.6.1 Security Object (ID 0) [500-549]

### 6.1.6.2 Server Object (ID 1) [550-599]

### 6.1.6.2.1 LightweightM2M-1.0-int-551 – Querying the readable resources of object

<b>Test Case Id</b>	LightweightM2M-1.0-int-551
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Querying the readable resources of object 1
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A READ operation from server on the resource has been received by the client. This test has to be run on the following resources:</p> <ul style="list-style-type: none"> <li>a) Short server ID</li> <li>b) Lifetime</li> <li>c) Default minimum period</li> <li>d) Default maximum period</li> <li>e) Disable timeout</li> <li>f) Notification storing when disabled or offline</li> <li>g) Binding</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. READ (CoAP GET) on the resource, with the CoAP Accept option value “0” to indicate the “text/plain” content format</li> <li>2. The server receives success message (2.05 Content) and the requested value in the corresponding Plain Text format</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server receives the status code “2.05” for READ success</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The server receives the requested information and displays the resource value to the user</li> </ol>

### 6.1.6.2.2 LightweightM2M-1.0-int-555 – Setting the writable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-555
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Setting the writable resources of object 1
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from server on the resource has been received by the client. This test has to be run for the following resources:</p> <ul style="list-style-type: none"> <li>a) Lifetime</li> <li>b) Default minimum period</li> <li>c) Default maximum period</li> <li>d) Disable timeout</li> <li>e) Notification storing when disabled or offline</li> <li>f) Binding</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. WRITE (CoAP PUT/POST) on the resource with a value admissible with regards to LWM2M technical specification</li> <li>2. Server receives success message (2.04 Changed)</li> <li>3. The server READs the result of the WRITE operation by querying the resource.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server receives the status code “2.04”</li> <li>2. The resource value has changed according to WRITE request</li> </ol>

### 6.1.6.2.3 LightweightM2M-1.0-int-560 – Observation and notification of observable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-560
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Sending the observation policy to the device for resources of object 1
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> </ul>
<b>Test Procedure</b>	<p>The Server establishes an Observation relationship with the Client to acquire condition notifications about observable resources. This test has to be run for the following resources:</p> <ul style="list-style-type: none"> <li>a) Short server ID</li> <li>b) Lifetime</li> <li>c) Default minimum period</li> <li>d) Default maximum period</li> <li>e) Disable timeout</li> <li>f) Notification storing when disabled or offline</li> <li>g) Binding</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server communicates to the device min/max period, threshold value and step with a WRITE ATTRIBUTE (CoAP PUT) operation</li> <li>2. The server sends OBSERVE (CoAP Observe Option) message to activate reporting</li> <li>3. The client reports requested information with a NOTIFY message (CoAP response)</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server has received the requested information and displays the resource value to the user</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The values returned by the client in each Notify are relevant with regards to the threshold value, the min/max period and the step</li> </ol>

### 6.1.6.3 Access Control Object (ID 2) [600-649]

### 6.1.6.4 LWM2M Server (ID 3) [650-699]

## 6.1.6.4.1 LightweightM2M-1.0-int-651 – Querying the readable resources of object

<b>Test Case Id</b>	LightweightM2M-1.0-int-651
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Querying the readable resources of object 3
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>o Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A READ operation from server on the resource has been received by the client. This test has to be run on the following resources:</p> <ul style="list-style-type: none"> <li>a) Manufacturer</li> <li>b) Device type</li> <li>c) Model number</li> <li>d) Serial number</li> <li>e) Hardware version</li> <li>f) Firmware version</li> <li>g) Software version</li> <li>h) Available power sources</li> <li>i) Power source voltage</li> <li>j) Power source current</li> <li>k) Battery level</li> <li>l) Battery status</li> <li>m) Memory free</li> <li>n) Memory total</li> <li>o) Error code</li> <li>p) Current time</li> <li>q) UTC offset</li> <li>r) Timezone</li> <li>s) Supported binding and modes</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. READ (CoAP GET) on the resource, with the CoAP Accept option value “0” to indicate the “text/plain” content format</li> <li>2. The server receives success message (2.05 Content) and the requested value in the corresponding Plain Text format</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server receives the status code “2.05” for READ success</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The server receives the requested information and displays the resource value to the user</li> </ol>

#### 6.1.6.4.2 LightweightM2M-1.0-int-652 – Querying the firmware version from the client

<b>Test Case Id</b>	LightweighthM2M-1.0-int-652
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Querying the firmware version of the firmware on the managed device
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<ol style="list-style-type: none"> <li>1. A READ operation from server on the resource has been received by the client.</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. READ (COAP GET) on device object resource “firmware version”, with the CoAP Accept option value “0” to indicate the “text/plain” content format;</li> <li>b. Server receives success message (2.05 Content) and the requested value in the corresponding Plain Text format.</li> </ol>
<b>IPass-Criteria</b>	<ol style="list-style-type: none"> <li>1. Server has received the requested information and displays to the user the following information: <ul style="list-style-type: none"> <li>• Firmware version</li> </ul> </li> </ol>

#### 6.1.6.4.3 LightweightM2M-1.0-int-655 – Setting the writable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-655
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Setting the writable resources of object 3
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from server on the resource has been received by the client. This test has to be run for the following resources:</p> <ol style="list-style-type: none"> <li>a) Current time</li> <li>b) UTC offset</li> <li>c) Timezone</li> </ol> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. WRITE (CoAP PUT/POST) on the resource with a value admissible with regards to LWM2M technical specification</li> <li>2. Server receives success message (2.04 Changed)</li> <li>3. The server READs the result of the WRITE operation by querying the resource.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server receives the status code “2.04”</li> <li>2. The resource value has changed according to WRITE request</li> </ol>

#### 6.1.6.4.4 LightweightM2M-1.0-int-660 – Observation and notification of observable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-660
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Sending the observation policy to the device for resources of object 3
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> </ul>
<b>Test Procedure</b>	<p>The Server establishes an Observation relationship with the Client to acquire condition notifications about observable resources. This test has to be run for the following resources:</p> <ul style="list-style-type: none"> <li>a) Manufacturer</li> <li>b) Device type</li> <li>c) Model number</li> <li>d) Serial number</li> <li>e) Hardware version</li> <li>f) Firmware version</li> <li>g) Software version</li> <li>h) Available power sources</li> <li>i) Power source voltage</li> <li>j) Power source current</li> <li>k) Battery level</li> <li>l) Battery status</li> <li>m) Memory free</li> <li>n) Memory total</li> <li>o) Error code</li> <li>p) Current time</li> <li>q) UTC offset</li> <li>r) Timezone</li> <li>s) Supported binding and modes</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server communicates to the device min/max period, threshold value and step with a WRITE ATTRIBUTE (CoAP PUT) operation</li> <li>2. The server sends OBSERVE (CoAP Observe Option) message to activate reporting</li> <li>3. The client reports requested information with a NOTIFY message (CoAP response)</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server has received the requested information and displays the resource value to the user</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The values returned by the client in each Notify are relevant with regards to the threshold value, the min/max period and the step</li> </ol>

### 6.1.6.5 LWM2M Connectivity Monitoring (ID 4) [700-749]

#### 6.1.6.5.1 LightweightM2M-1.0-int-701 – Querying the readable resources of object

<b>Test Case Id</b>	LightweightM2M-1.0-int-701
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Querying the readable resources of object 4
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A READ operation from server on the resource has been received by the client. This test has to be run on the following resources:</p> <ul style="list-style-type: none"> <li>a) Network bearer</li> <li>b) Available network bearer</li> <li>c) Radio signal strength</li> <li>d) Link quality</li> <li>e) IP addresses</li> <li>f) Router IP addresses</li> <li>g) Link utilization</li> <li>h) APN</li> <li>i) Cell ID</li> <li>j) SMNC</li> <li>k) SMCC</li> </ul> <p>Normal flow:</p> <ul style="list-style-type: none"> <li>1. READ (CoAP GET) on the resource, with the CoAP Accept option value “0” to indicate the “text/plain” content format</li> <li>2. The server receives success message (2.05 Content) and the requested value in the corresponding Plain Text format</li> </ul>
<b>Pass-Criteria</b>	<ul style="list-style-type: none"> <li>1. The server receives the status code “2.05” for READ success</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The server receives the requested information and displays the resource value to the user</li> </ul>

#### 6.1.6.5.2 LightweightM2M-1.0-int-705 – Setting the writable resources

There is no writable resources for this object.

### 6.1.6.5.3 LightweightM2M-1.0-int-710 – Observation and notification of observable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-710
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Sending the observation policy to the device for resources of object 4
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> </ul>
<b>Test Procedure</b>	<p>The Server establishes an Observation relationship with the Client to acquire condition notifications about observable resources. This test has to be run for the following resources:</p> <ul style="list-style-type: none"> <li>a) Network bearer</li> <li>b) Available network bearer</li> <li>c) Radio signal strength</li> <li>d) Link quality</li> <li>e) IP addresses</li> <li>f) Router IP address</li> <li>g) Link utilization</li> <li>h) APN</li> <li>i) Cell ID</li> <li>j) SMNC</li> <li>k) SMCC</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server communicates to the device min/max period, threshold value and step with a WRITE ATTRIBUTE (CoAP PUT) operation</li> <li>2. The server sends OBSERVE (CoAP Observe Option) message to activate reporting</li> <li>3. The client reports requested information with a NOTIFY message (CoAP response)</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server has received the requested information and displays the resource value to the user</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The values returned by the client in each Notify are relevant with regards to the threshold value, the min/max period and the step</li> </ol>

## 6.1.6.6 Firmware Update Object (ID 5) [750-799]

### 6.1.6.6.1 LightweightM2M-1.0-int-751 – Querying the readable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-751
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Querying the readable resources of Firmware Update Object
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>o Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A READ operation from server on the resource has been received by the client. This test has to be run on the following resources:</p> <ul style="list-style-type: none"> <li>a) State</li> <li>b) Update supported objects</li> <li>c) Update result</li> <li>d) Pkgname</li> <li>e) Pkgversion</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. READ (CoAP GET) on the resource, with the CoAP Accept option value “0” to indicate the “text/plain” content format</li> <li>2. The server receives success message (2.05 Content) and the requested value in the corresponding Plain Text format</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server receives the status code “2.05” for READ success</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The server receives the requested information and displays the resource value to the user</li> </ol>

### 6.1.6.6.2 LightweightM2M-1.0-int-755 – Setting the writable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-755
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Setting the writable resources of Firmware Update Object
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>o Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from server on the resource has been received by the client. This test has to be run for the following resources:</p> <ul style="list-style-type: none"> <li>a) Package</li> <li>b) Package URI</li> <li>c) Update supported objects</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. WRITE (CoAP PUT/POST) on the resource with a value admissible with regards to LWM2M technical specification</li> <li>2. Server receives success message (2.04 Changed)</li> <li>3. The server READs the result of the WRITE operation by querying the resource.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server receives the status code “2.04”</li> <li>2. The resource value has changed according to WRITE request</li> </ol>

### 6.1.6.6.3 LightweightM2M-1.0-int-760 – Observation and notification of observable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-760
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Sending the observation policy to the device for resources of Firmware Update Object
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> </ul>
<b>Test Procedure</b>	<p>The Server establishes an Observation relationship with the Client to acquire condition notifications about observable resources. This test has to be run for the following resources:</p> <ul style="list-style-type: none"> <li>a) State</li> <li>b) Update supported objects</li> <li>c) Update result</li> <li>d) Pkgname</li> <li>e) Pkgversion</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server communicates to the device min/max period, threshold value and step with a WRITE ATTRIBUTE (CoAP PUT) operation</li> <li>2. The server sends OBSERVE (CoAP Observe Option) message to activate reporting</li> <li>3. The client reports requested information with a NOTIFY message (CoAP response)</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server has received the requested information and displays the resource value to the user</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The values returned by the client in each Notify are relevant with regards to the threshold value, the min/max period and the step</li> </ol>

### 6.1.6.6.4 LightweightM2M-1.0-int-770 – Successful Firmware update (via COAP)

<b>Test Case Id</b>	LightweightM2M-1.0-int-770
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Perform a device firmware update remotely triggered by the LWM2M server in using Package Resource (CoAP mechanisms)
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> <li>○ Firmware Update is available on the Server</li> <li>○ State is to “0” (Idle) or “1” (Downloaded)</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from the server on /5/0/0 (Package) is received by the client</p> <p>Normal flow:</p>

	<ol style="list-style-type: none"> <li>1. <b>Step 1 – Write</b> <ol style="list-style-type: none"> <li>a. The server delivers the firmware to the device through a WRITE (CoAP PUT/POST) operation on /5/0/0 (Package)</li> <li>b. Update Result is set to “0” (Initial value)</li> <li>c. When the download starts, State is set to “1” (Downloading)</li> <li>d. A READ (CoAP GET) on /5/0/3 (State) provides the status of the firmware download to the server. The server may send repeated READs or OBSERVE the resource to determine when the download is completed.</li> <li>e. When the download is completed, State is set to “2” (Downloaded)</li> </ol> </li> <li>2. <b>Step 2 – Execute</b> <ol style="list-style-type: none"> <li>a. When the download is completed, the server initiates a firmware update by EXECUTE (CoAP POST) /5/0/2 (Update)</li> <li>b. State is set to “3” (Updating)                     <p style="margin-left: 20px;">If firmware is successfully updated</p> <ol style="list-style-type: none"> <li>b.1 Update Result is set to “1” (Firmware updated successfully)</li> <li>b.2 The device is automatically rebooting.</li> </ol> </li> <li>c. The server READs Update Result to know the result of the firmware update procedure.</li> </ol> </li> </ol>
<p><b>Pass-Criteria</b></p>	<ol style="list-style-type: none"> <li>1. <b>Step 1 – Write</b> <ol style="list-style-type: none"> <li>a. The server receives the status code “2.04” for WRITE success</li> <li>b. State is set to “1” (Downloading) during the step and is “2” at the end of the step (Downloaded)</li> <li>c. Update Result is “0” (Initial Value) during the whole step</li> <li>d. New firmware is present on the device</li> </ol> </li> <li>2. <b>Step 2 – Execute</b> <ol style="list-style-type: none"> <li>a. State is “3” (Updating) when EXECUTE has been sent</li> <li>b. The server receives the status code “2.04” for EXECUTE success</li> <li>c. The device is rebooted</li> <li>d. New firmware is updated on the device</li> <li>e. State is “0” (Idle) at the end of the step</li> <li>f. Update Result is “1” at the end of the step (Firmware updated successfully)</li> </ol> </li> </ol>

### 6.1.6.6.5 LightweightM2M-1.0-int-771 – Successful Firmware update (via alternative mechanism)

<b>Test Case Id</b>	LightweightM2M-1.0-int-771
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Perform a device firmware update remotely triggered by the LWM2M server in using Package URI Resource
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> <li>○ Firmware Update is available on the Server</li> <li>○ State is to “0” (Idle) or “1” (Downloaded)</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from the server on /5/0/1 (Package URI) is received by the client Normal flow:</p> <ol style="list-style-type: none"> <li><b>1. Step 1 – Write</b> <ol style="list-style-type: none"> <li>a. The server delivers the firmware URI to the device through a WRITE (CoAP PUT/POST) operation on /5/0/1 (Package URI)</li> <li>b. Update Result is set to “0” (Initial value)</li> <li>c. The Device downloads the firmware from the URI via an alternative mechanism (not CoAP)</li> <li>d. When the download starts, State is set to “1” (Downloading)</li> <li>e. A READ (CoAP GET) on /5/0/3 (State) provides the status of the firmware download to the server. The server may send repeated READs or OBSERVE the resource to determine when the download is completed.</li> <li>f. When the download is completed, State is set to “2” (Downloaded)</li> </ol> </li> <li><b>2. Step 2 – Execute</b> <ol style="list-style-type: none"> <li>a. When the download is completed, the server initiates a firmware update by EXECUTE (CoAP POST) /5/0/2 (Update)</li> <li>b. State is set to “3” (Updating)</li> <li>c. Firmware is successfully updated               <ol style="list-style-type: none"> <li>c.1 Update Result is set to “1” (Firmware updated successfully)</li> <li>c.2 The device is automatically rebooting.</li> </ol> </li> <li>d. The server READs Update Result to know the result of the firmware update procedure.</li> </ol> </li> </ol>

<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li><b>1. Step 1 – Write</b> <ol style="list-style-type: none"> <li>a. The server receives the status code “2.04” for WRITE success</li> <li>b. State is set to “1” (Downloading) during the step and is “2” at the end of the step (Downloaded)</li> <li>c. Update Result is “0” (Initial Value) during the whole step</li> <li>d. New firmware is present on the device</li> </ol> </li> <li><b>2. Step 2 – Execute</b> <ol style="list-style-type: none"> <li>a. State is “3” (Updating) when EXECUTE has been sent</li> <li>b. The server receives the status code “2.04” for EXECUTE success</li> <li>c. The device is rebooted</li> <li>d. New firmware is updated on the device</li> <li>e. State is “0” (Idle) at the end of the step</li> <li>f. Update Result is “1” at the end of the step (Firmware updated successfully)</li> </ol> </li> </ol>
----------------------	---

#### 6.1.6.6.6 LightweightM2M-1.0-int-772 – Error Case: firmware package not downloaded

<b>Test Case Id</b>	LightweightM2M-1.0-int-772
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Try to perform a device firmware installation when there is no downloaded firmware package
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> <li>○ Firmware Update is available on the Server</li> <li>○ State (/5/0/3) is different from “2” (Downloaded)</li> </ul>
<b>Test Procedure</b>	<p>An EXECUTE operation from the server on /5/0/2 (Update) is received by the client</p> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The client does nothing</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. New firmware is not installed on the device</li> <li>2. The device is not rebooted</li> <li>3. State (/5/0/3) does not change</li> <li>4. Update Result (/5/0/5) is not changed</li> <li>5. The server receives the status code “4.05” for method not allowed</li> </ol>

## 6.1.6.6.7 LightweightM2M-1.0-int-773 – Error Case: not enough storage

<b>Test Case Id</b>	LightweightM2M-1.0-int-773
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Try to perform a device firmware update remotely triggered by the LWM2M Server with a firmware package exceeding the device storage memory capacity.
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> <li>○ Firmware Update is available on the Server</li> <li>○ State (/5/0/3) is set to “0” (Idle)</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from the server on /5/0/0 (Package) with a firmware package exceeding the device storage memory capacity, is received by the client</p> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server delivers the firmware package to the device through a WRITE (CoAP PUT/POST) operation on /5/0/0 (Package)</li> <li>2. Update Result is set to “0” (Initial value)</li> <li>3. When the download starts, State is set to “1” (Downloading)</li> <li>4. A READ (CoAP GET) on /5/0/3 (State) provides the status of the firmware download to the server. The server may send repeated READs or OBSERVE the resource to determine when the download is completed.</li> <li>5. Before the end of download, the device runs out of storage and cannot finish the download (State still keeps the value “1”: Downloading).</li> <li>6. The client removes what was downloaded</li> <li>7. /5/0/3 (State) is set to “0” (Idle)</li> <li>8. /5/0/5 (Update Result) is set to “2” (Not enough storage for the new firmware package)</li> <li>9. The server READs Update Result to know the result of the firmware update procedure.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. New software is not installed on the device</li> <li>2. New software is not present on the device</li> <li>3. The device is not rebooted</li> <li>4. The Server receives the status code "2.04" for WRITE success</li> <li>5. /5/0/5 (Update Result) is “0” (Initial) during the step and then “1” during download and is “2” (Not enough storage for the new firmware package) at the end of the step</li> <li>6. /5/0/3 (State) is “1” (Downloading) during the step and is “0” at the end of the step</li> <li>7. State never reaches the Downloaded value (“3”)</li> </ol>

## 6.1.6.6.8 LightweightM2M-1.0-int-774 – Error Case: out of memory

<b>Test Case Id</b>	LightweightM2M-1.0-int-774
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Try to perform a device firmware update remotely triggered by the LWM2M Server while the Device runs out of memory during download
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Prepare a package with a size big enough to make the Client run out of memory when downloading it</li> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> <li>○ Firmware Update is available on the Server</li> <li>○ State is set to “0” (Idle)</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from the server on /5/0/0 (Package) is received by the Client</p> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server delivers the firmware to the device through a WRITE (CoAP PUT/POST) operation on /5/0/0 (Package)</li> <li>2. Update Result is set to “0” (Initial)</li> <li>3. When the download starts, State is set to “1” (Downloading)</li> <li>4. A READ (CoAP GET) on /5/0/3 (State) provides the status of the firmware download to the server. The server may send repeated READs or OBSERVE the resource to determine when the download is completed.</li> <li>5. Before the end of download, the device runs out of memory and cannot finish the download (State still keeps the value “1” :Downloading)</li> <li>6. The client removes what was downloaded</li> <li>7. /5/0/3 (State) is set to “0” (Idle)</li> <li>8. /5/0/5 (Update Result) is set to “3” (Out of memory during downloading process)</li> <li>9. The server READs Update Result to know the result of the firmware update procedure.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. New firmware is not installed on the device</li> <li>2. New firmware is not present on the device</li> <li>3. The device is not rebooted</li> <li>4. The server receives the status code “2.04” for WRITE success</li> <li>5. /5/0/5 (Update Result) is “0” (Initial) during the step and is “3” (Out of memory during downloading process) at the end of the step.</li> <li>6. /5/0/3 (State) is “1” (Downloading) during the step and is “0” (Idle) at the end of the step</li> <li>7. State never reaches the Downloaded value (“3”)</li> </ol>

### 6.1.6.6.9 LightweightM2M-1.0-int-775 – Error Case: Connection lost during download (package URI)

<b>Test Case Id</b>	LightweightM2M-1.0-int-775
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Try to perform a device firmware update remotely triggered by the LWM2M server while connection is lost during download
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> <li>○ Firmware Update is available on the Server</li> <li>○ State is set to “0” (Idle)</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from the server on /5/0/0 (Package) is received by the client</p> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server delivers the firmware to the device through a WRITE (CoAP PUT/POST) operation on /5/0/0 (Package)</li> <li>2. Update Result is set to “0” (Initial)</li> <li>3. When the download starts, State is set to “1” (Downloading)</li> <li>4. A READ (CoAP GET) on /5/0/3 (State) provides the status of the firmware download to the server. The server may send repeated READs or OBSERVE the resource to determine when the download is completed.</li> <li>5. Before the end of download, the connection is lost and the client cannot finish the download (State still keeps the value “1” :Downloading)</li> <li>6. The client removes what was downloaded</li> <li>7. /5/0/3 (State) is set to “0” (Idle)</li> <li>8. /5/0/5 (Update Result) is set to “4” (Connection lost during downloading process.)</li> <li>9. The server READs Update Result to know the result of the software installation procedure.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. New firmware is not installed on the device</li> <li>2. New firmware is not present on the device</li> <li>3. The device is not rebooted</li> <li>4. The server receives the status code “2.04” for WRITE success</li> <li>5. /5/0/5 (Update Result) is “0” during the step and is “4” (Connection lost during downloading process) at the end of the step.</li> <li>6. /5/0/3 (State) is “1” (Downloading) during the step and is “0” (Idle) at the end of the step</li> <li>7. State never reaches the Downloaded value (“3”)</li> </ol>

## 6.1.6.6.10 LightweightM2M-1.0-int-776 – Error Case: CRC check fail

<b>Test Case Id</b>	LightweightM2M-1.0-int-776
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Try to perform a device firmware update remotely triggered by the LWM2M Server while the downloaded package does not pass the integrity check
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> <li>○ Firmware Update is available on the Server</li> <li>○ State is set to “0” (Idle)</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from the server on /5/0/0 (Package) is received by the client</p> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server delivers the firmware to the device through a WRITE (CoAP PUT/POST) operation on /5/0/0 (Package)</li> <li>2. Update Result is set to “0” (Initial)</li> <li>3. When the download starts, State is set to “1” (Downloading)</li> <li>4. A READ (CoAP GET) on /5/0/3 (State) provides the status of the firmware download to the server. The server may send repeated READs or OBSERVE the resource to determine when the download is completed.</li> <li>5. The package integrity check fails</li> <li>6. The client removes what was downloaded</li> <li>7. /5/0/3 (State) is set to “0” (Initial)</li> <li>8. /5/0/5 (Update Result) is set to “5” (CRC check failure for new downloaded package)</li> <li>9. The server READs Update Result to know the result of the firmware update procedure.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. New firmware is not installed on the device</li> <li>2. New firmware is not present on the device</li> <li>3. The device is not rebooted</li> <li>4. The server receives the status code “2.04” for WRITE success</li> <li>5. /5/0/5 (Update Result) is “0” (Initial) during the step and is “5” (CRC check failure for new downloaded package) at the end of the step</li> <li>6. /5/0/3 (State) is set to “1” (Downloading) during the step and is “0” (Idle) at the end of the step</li> <li>7. State never reaches the Downloaded value (“3”)</li> </ol>

### 6.1.6.6.11 LightweightM2M-1.0-int-777 – Error Case: unsupported package type

<b>Test Case Id</b>	LightweightM2M-1.0-int-777
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Try to perform a device firmware update remotely triggered by the LWM2M server with an unsupported package type
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> <li>○ Firmware Update is available on the Server</li> <li>○ State is set to “0” (Idle)</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from the server on /5/0/0 (Package) with a package with an unsupported type is received by the client</p> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server delivers the firmware package to the device through a WRITE (CoAP PUT/POST) operation on /5/0/0 (Package)</li> <li>2. Update Result is set to “0” (Initial)</li> <li>3. When the download starts, State is set to “1” (Downloading)</li> <li>4. A READ (CoAP GET) on /5/0/3 (State) provides the status of the firmware download to the Server. The Server may send repeated READs or OBSERVE the resource to determine when the download is completed.</li> <li>5. The package type is not supported</li> <li>6. The client removes what was downloaded</li> <li>7. /5/0/3 (State) is set to “0” (Idle)</li> <li>8. /5/0/5 (Update Result) is set to “6” (Unsupported package type)</li> <li>9. The server READs Update Result to know the result of the firmware update procedure.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. New firmware is not installed on the device</li> <li>2. New firmware is not present on the device</li> <li>3. The device is not rebooted</li> <li>4. The server receives the status code “2.04” for WRITE success</li> <li>5. Update Result is “0” during the step and is “6” (Unsupported package type) at the end of the step</li> <li>6. State is set to “1” (Downloading) during the step and is “0” (Idle) at the end of the step</li> </ol>

## 6.1.6.6.12 LightweightM2M-1.0-int-778 – Error Case: invalid URI (package URI)

<b>Test Case Id</b>	LightweightM2M-1.0-int-778
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Try to perform a device firmware update remotely triggered by the LWM2M server with an invalid URI
<b>Preconditions</b>	<p>Device is registered at the LWM2M server</p> <p>Device is switched on and operational</p> <p>Firmware Update is available on the Server</p> <p>State is set to “0” (Idle)</p>
<b>Test Procedure</b>	<p>A WRITE operation from the server on /5/0/1 (Package URI) with an invalid URI is received by the client</p> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server delivers the invalid firmware URI to the device through a WRITE (CoAP PUT/POST) operation on /5/0/1 (Package URI)</li> <li>2. /5/0/5 (Update Result) is set to “0” (Initial)</li> <li>3. A READ (CoAP GET) on /5/0/3 (State) provides the status of the firmware download to the server. The state should indicate that the download did not start (State = “0”)</li> <li>4. /5/0/5 (Update Result) is set to “7” (Invalid URI)</li> <li>5. The server READs /5/0/5 (Update Result) to know the result of the firmware update procedure.</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. New firmware is not installed on the device</li> <li>2. The device is not rebooted</li> <li>3. The server receives the status code “2.04” for WRITE success</li> <li>4. /5/0/5 (Update Result) is set to “0” during the step and is “7” (Invalid URI) at the end of the step</li> <li>5. /5/0/3 (State) is “0” (Idle) during the whole step</li> <li>6. State always keeps the Idle (“0”) value.</li> </ol>

## 6.1.6.6.13 LightweightM2M-1.0-int-779 – Error Case: Unsuccessful Firmware Update

<b>Test Case Id</b>	LightweightM2M-1.0-int-779
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Perform a device firmware update remotely triggered by the LWM2M server in using Package Resource (CoAP mechanisms) but with installation failure
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> <li>○ Firmware Update is available on the Server</li> <li>○ State is to “0” (Idle) or “1” (Downloaded)</li> </ul>
<b>Test Procedure</b>	<p>A WRITE operation from the server on /5/0/0 (Package) is received by the client</p> <p>Normal flow:</p> <ol style="list-style-type: none"> <li><b>1. Step 1 – Write</b> <ol style="list-style-type: none"> <li>a. The server delivers the firmware to the device through a WRITE (CoAP PUT/POST) operation on /5/0/0 (Package)</li> <li>b. Update Result is set to “0” (Initial value)</li> <li>c. When the download starts, State is set to “1” (Downloading)</li> <li>d. A READ (CoAP GET) on /5/0/3 (State) provides the status of the firmware download to the server. The server may send repeated READs or OBSERVE the resource to determine when the download is completed.</li> <li>e. When the download is completed, State is set to “2” (Downloaded)</li> </ol> </li> <li><b>2. Step 2 – Execute</b> <ol style="list-style-type: none"> <li>a. When the download is completed, the server initiates a firmware update by EXECUTE (CoAP POST) on /5/0/2 (Update) Resource</li> <li>b. State is set to “3” (Updating)</li> <li>c. Firmware updates fails               <ol style="list-style-type: none"> <li>c.1 Update Result is set to “8” (Firmware update failed )</li> <li>c.2 The device is not rebooted</li> <li>c.3 State is set back to “2” (Downloaded)</li> </ol> </li> <li>d. The server READs Update Result to know the result of the firmware update procedure.</li> </ol> </li> </ol>

<b>Pass-Criteria</b>	<ol style="list-style-type: none"><li>1. <b>Step 1 – Write</b><ol style="list-style-type: none"><li>a. The server receives the status code “2.04” for WRITE success</li><li>b. /5/0/3 (State) is “1” (Downloading) during the step and is “2” (Downloaded) at the end of the step</li><li>c. /5/0/5 (Update Result) is “0” (Initial Value) during the whole step</li><li>d. New firmware is present on the device</li></ol></li><li>2. <b>Step 2 – Execute</b><ol style="list-style-type: none"><li>a. /5/0/3 (State) is “3” (Updating) and /5/0/5 (Update Result) is “0” (Initial) when EXECUTE on /5/0/2 (Update) Resource has been sent</li><li>b. The server receives the status code “2.04” for EXECUTE success</li><li>c. The device is not rebooted</li><li>d. New firmware is not updated on the device</li><li>e. /5/0/3 (State) is “2” (Downloaded) at the end of the step</li><li>f. /5/0/5 (Update Result) is “8” (Firmware update failed) at the end of the step</li></ol></li></ol>
----------------------	---

### 6.1.6.7 Location Object (ID 6) [800-849]

#### 6.1.6.7.1 LightweightM2M-1.0-int-801 – Querying the readable resources of object

<b>Test Case Id</b>	LightweightM2M-1.0-int-801
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Querying the readable resources of object 6
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A READ operation from server on the resource has been received by the client. This test has to be run on the following resources:</p> <ul style="list-style-type: none"> <li>a) Latitude</li> <li>b) Longitude</li> <li>c) Altitude</li> <li>d) Uncertainty</li> <li>e) Velocity</li> <li>f) Timestamp</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. READ (CoAP GET) on the resource, with the CoAP Accept option value “0” to indicate the “text/plain” content format</li> <li>2. The server receives success message (2.05 Content) and the requested value in the corresponding Plain Text format</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server receives the status code “2.05” for READ success</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The server receives the requested information and displays the resource value to the user</li> </ol>

#### 6.1.6.7.2 LightweightM2M-1.0-int-805 – Setting the writable resources

There are no writable resources for this object.

#### 6.1.6.7.3 LightweightM2M-1.0-int-810 – Observation and notification of observable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-810
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Sending the observation policy to the device for resources of object 6
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> </ul>
<b>Test Procedure</b>	<p>The Server establishes an Observation relationship with the Client to acquire condition notifications about observable resources. This test has to be run for the following resources:</p> <ul style="list-style-type: none"> <li>a) Latitude</li> <li>b) Longitude</li> <li>c) Altitude</li> <li>d) Uncertainty</li> </ul>

	<ul style="list-style-type: none"> <li>e) Velocity</li> <li>f) Timestamp</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server communicates to the device min/max period, threshold value and step with a WRITE ATTRIBUTE (CoAP PUT) operation</li> <li>2. The server sends OBSERVE (CoAP Observe Option) message to activate reporting</li> <li>3. The client reports requested information with a NOTIFY message (CoAP response)</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server has received the requested information and displays the resource value to the user</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The values returned by the client in each Notify are relevant with regards to the threshold value, the min/max period and the step</li> </ol>

## 6.1.6.8 Connectivity Statistics (ID 7) [900-949]

### 6.1.6.8.1 LightweightM2M-1.0-int-901 – Querying the readable resources of object

<b>Test Case Id</b>	LightweightM2M-1.0-int-901
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Querying the readable resources of object 7
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered with the Server</li> </ul>
<b>Test Procedure</b>	<p>A READ operation from server on the resource has been received by the client. This test has to be run on the following resources:</p> <ul style="list-style-type: none"> <li>a) SMS Tx counter</li> <li>b) SMS Rx counter</li> <li>c) Tx data</li> <li>d) Rx data</li> <li>e) Max message size</li> <li>f) Average message size</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. READ (CoAP GET) on the resource, with the CoAP Accept option value “0” to indicate the “text/plain” content format</li> <li>2. The server receives success message (2.05 Content) and the requested value in the corresponding Plain Text format</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server receives the status code “2.05” for READ success</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The server receives the requested information and displays the resource value to the user</li> </ol>

### 6.1.6.8.2 LightweightM2M-1.0-int-905 – Setting the writable resources

There are no writable resources for this object.

### 6.1.6.8.3 LightweightM2M-1.0-int-910 – Observation and notification of observable resources

<b>Test Case Id</b>	LightweightM2M-1.0-int-910
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Sending the observation policy to the device for resources of object 7
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is registered at the LWM2M server</li> <li>○ Device is switched on and operational</li> </ul>
<b>Test Procedure</b>	<p>The Server establishes an Observation relationship with the Client to acquire condition notifications about observable resources. This test has to be run for the following resources:</p> <ul style="list-style-type: none"> <li>a) SMS Tx counter</li> <li>b) SMS Rx counter</li> <li>c) Tx data</li> <li>d) Rx data</li> <li>e) Max message size</li> <li>f) Average message size</li> </ul> <p>Normal flow:</p> <ol style="list-style-type: none"> <li>1. The server communicates to the device min/max period, threshold value and step with a WRITE ATTRIBUTE (CoAP PUT) operation</li> <li>2. The server sends OBSERVE (CoAP Observe Option) message to activate reporting</li> <li>3. The client reports requested information with a NOTIFY message (CoAP response)</li> </ol>
<b>Pass-Criteria</b>	<ol style="list-style-type: none"> <li>1. The server has received the requested information and displays the resource value to the user</li> <li>2. The value returned by the client is admissible with regards of LWM2M technical specification</li> <li>3. The values returned by the client in each Notify are relevant with regards to the threshold value, the min/max period and the step</li> </ol>

## 6.2 LWM2M Additional Objects Test cases [1000-1999]

### 6.2.1 Lock and Wipe Object (ID 8) [1000-1099]

<Test Cases to fill-up>

### 6.2.2 Software Management Object (ID 9) [1100-1199]

<Test Cases to fill-up>

## 6.2.3 Connectivity Management Objects (ID 10, 11, 12, 13) [1200-1499]

### 6.2.3.1 LightweightM2M-CONMGMT-1.0-int-1201 – APN configuration

<b>Test Case Id</b>	LightweightM2M-CONMGMT-1.0-int-1201
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Creating and enabling a new APN profile
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is switched on and operational</li> <li>○ Device is registered at the LWM2M server</li> <li>○ Device has a Cellular Network Connectivity object and one instance of an APN Connection Profile object. Cellular connectivity is established with the parameters given in the APN Connection Profile object instance.</li> </ul>
<b>Test Procedure</b>	<p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. CREATE (COAP POST) operation is performed by the server targeting 11/1 to create a 2<sup>nd</sup> instance of the APN connection profile object with a new APN which is not yet active.</li> <li>b. Server receives success message (2.01 Created)</li> <li>c. Client is triggered to do a REGISTER operation e.g. by power off/on</li> <li>d. REGISTER message (COAP POST) is sent from client to server including information about the supported Objects and Object Instances including the new instance of the APN Connection Profile object</li> <li>e. Client receives 2.01 Created indicating successful completion of register message.</li> <li>f. Server activates the new APN Connection Profile by changing Enable status to True by WRITE 11/1/3 (COAP PUT)</li> <li>g. Server receives success message (2.04 Changed)</li> <li>h. Server reads the list of active APN Connection Profiles by performing READ 10/4000</li> <li>i. Server receives success message (2.05 Content) indicating the active APN Connection Profiles</li> </ol>
<b>Pass-Criteria</b>	<ul style="list-style-type: none"> <li>● New APN connection profile is active</li> </ul> <p>NOTE: In case the device only supports one active APN profile this test is passed when the new APN profile is activated.</p>

### 6.2.3.2 LightweightM2M-CONMGMT-1.0-int-1202 – Bearer Selection

<b>Test Case Id</b>	LightweightM2M-CONMGMT-1.0-int-1202
<b>Test Object</b>	Client and Server
<b>Test Case Description</b>	Controlling bearers using Bearer Selection Object
<b>Tool</b>	n/a
<b>Test code</b>	n/a
<b>Preconditions</b>	<ul style="list-style-type: none"> <li>○ Device is switched on and operational</li> <li>○ Device is registered at the LWM2M server</li> <li>○ Device has a Cellular Network Connectivity object and one instance of an APN Connection Profile object. Cellular connectivity is established with the parameters given in the APN Connection Profile object instance. Also, Device has a WLAN Connectivity object but WLAN radio is not enabled.</li> </ul>
<b>Test Procedure</b>	<p>Normal flow:</p> <ol style="list-style-type: none"> <li>a. CREATE (COAP POST) operation is performed by the server targeting 13/0 to create the instance of the Bearer selection object with Preferred Communication Bearer (13/0/0) as WLAN preferred.</li> <li>b. Server receives success message (2.01 Created)</li> <li>c. Client shall turn on the WLAN radio and use it for connectivity with the Server. Client shall send Update to the Server indicating the update in registration as the Client's IP address (and port) has changed.</li> <li>d. Server checks the status of the WLAN connectivity object by performing a READ on /12/0. The interface shall be enabled and running. The Server shall verify the values of Enable and Status resources for the same.</li> <li>e. Server performs WRITE operation on Preferred Communication Bearer (13/0/0) resource and updates its value to 3GPP PS Preferred.</li> <li>f. Client shall turn on the Cellular network connectivity (if not already enabled) and use it for connectivity with the Server. Client shall send Update to the Server indicating the update in registration as the Client's IP address (and port) has changed.</li> <li>g. Server checks the status of the Cellular Network Connectivity object by performing a READ on /10. The interface shall be enabled and running.</li> </ol>
<b>Pass-Criteria</b>	<ul style="list-style-type: none"> <li>• Bearer Selection Object is allowing the Server to control Client interface for communication</li> </ul>

### 6.2.4 Device Capability Management Object (ID 15) [1500-1599]

<Test Cases too fill-up>

## Appendix A. Change History

(Informative)

### A.1 Approved Version History

Reference	Date	Description
n/a	n/a	No prior version

### A.2 Draft/Candidate Version 1.0 History

Document Identifier	Date	Sections	Description
Draft Versions OMA-ETS-LightweightM2M-V1_0	18 Jun 2013	All	First Draft as agreed in OMA-IOP-MEC-2013-0083-INP_ETS_for_LWM2M
	17 Oct 2013	All	Cleaned up Version for the LWM2M Testfest in Las Vegas as agreed in OMA-IOP-MEC-2013-0103-CR_Clean_up_of_LWM2M_ETS
	20 Dec 2013	1, 2.1, 3.3, 5, 6.1.3, 6.2, 6.3, 6.4, 6.5	Incorporated CR: OMA-IOP-MEC-2013-0115-CR_LWM2M_ETS_Update Editorial changes
	19 Feb 2014	2.1, 6.1.4, 6.2.1, 6.2.2, 6.2.3, 6.4.1, 6.5, 6.6	Incorporated CR: OMA-IOP-MEC-2014-0005R01-CR_LWM2M_ETS_new_test_cases Editorial changes
Candidate Version OMA-ETS-LightweightM2M-V1_0	26 Feb 2014	n/a	Status changed to Candidate by TP TP Ref # OMA-TP-2014-0047-INP_LightweightM2M_V1_0_ETS_for_Candidate_approval
Draft Version OMA-ETS-LightweightM2M-V1_0	22 Jan 2015	6.7, 6.8	Incorporated CRs: OMA-IOP-MEC-2015-0001R01-CR_LWM2M_ETS_CONMGMT_test_case_for_APN_configuration OMA-IOP-MEC-2015-0002-CR_LWM2M_ETS_Location_Object_Test_Case OMA-IOP-MEC-2015-0003-CR_LWM2M_ETS_CONMGMT_test_case_for_Bearer_Selection Editorial changes
Candidate Version OMA-ETS-LightweightM2M-V1_0	03 Feb 2015	n/a	Status changed to Candidate by TP TP Ref # OMA-TP-2015-0042-INP_LightweightM2M_V1_0_ETS_for_Candidate_re_approval
Draft Versions OMA-ETS-LightweightM2M-V1_0	11 Aug 2015	6	Incorporated CR: OMA-IOP-MEC-2015-0007R01-CR_LWM2M_Tests_Cases_New_Structure_ Editorial changes
	03 Sep 2015	6.1.3.5, 6.1.6.2, 6.1.6.4, 6.1.6.6, 6.1.6.9.1, 6.1.6.9.2, 6.1.6.9.3, 6.1.6.11	Incorporated CRs: OMA-IOP-2015-0154R01-CR_LWM2M_ETS_SettingValues_int205 OMA-IOP-2015-0156R01-CR_LWM2M_ETS_Obj_1 OMA-IOP-2015-0157R01-CR_LWM2M_ETS_Obj_3 OMA-IOP-2015-0164R01-CR_LWM2M_ETS_Obj_4 OMA-IOP-2015-0165R01-CR_LWM2M_ETS_Obj_6 OMA-IOP-2015-0166R01-CR_LWM2M_ETS_Obj_7 Editorial changes
	16 Sep 2015	6.1.2.5, 6.1.6.8.1, 6.1.6.8.2, 6.1.6.8.5-6.1.6.8.15	Incorporated CRs: OMA-IOP-2015-0155R01-CR_LWM2M_ETS_BootStrapServer_int105 OMA-IOP-2015-0158R02-CR_LWM2M_ETS_FirmwareUpdate_Obj_5 Editorial changes

## Appendix B. Additional Information

### B.1 Example of Test Configuration and Setup

The following hardware components were part of a test setup.

- M2M device equipped with LWM2M client
- Computer that runs the browser interface to the LWM2M server component
- Server that runs the LWM2M server software
- USIM provisioned for use on the network.
- External appliance which is connected directly to M2M device (e.g. light, temperature sensor, motor).

In addition the demonstration setup shall include the following software components:

- Measurement software which enables to see e.g. LWM2M messages and CoAP messages.
  - The software shall enable
    - GUI to trigger the chosen test cases
    - To see the flow of information between client and server, e.g. on LWM2M protocol level and on CoAP transport level.